


EXPLOSIVE DRAWING



COMPONENTS LIST

| No | Description (Butir-Butir) | NFW35-1/2 | NFW40-1/2 | NFW45-1/2 | NFW50-1/2 | NFW55-1/2 |
|----|--|------------|------------|-------------|-------------|-------------|
| 1 | Plastic Knob (Pemulas Plastik) | KN-110 | KN-110 | KN-110 | KN-110 | KN-110 |
| 2 | Thermostat (Termostat) | TM-110 | TM-110 | TM-110 | TM-110 | TM-110 |
| 3 | Pilot Light (Lampu Pilot) | LE-PLRED | LE-PLRED | LE-PLRED | LE-PLRED | LE-PLRED |
| 4 | Heating Element (Unsur Pemanasan) | HT-NFW800W | HT-NFW800W | HT-NFW1.1KW | HT-NFW1.1KW | HT-NFW1.1KW |
| 5 | Oven Bulb (Mentol Oven) | LE-FW-LB | LE-FW-LB | LE-FW-LB | LE-FW-LB | LE-FW-LB |
| 6 | Shelving (Talam Alas) | NT-FW35B | NT-FW35B | NT-FW45B | NT-FW45B | NT-FW55B |
| 7 | Glass Door (Pintu Kaca) | GL-NFW35-D | GL-NFW40-D | GL-NFW45-D | GL-NFW50-D | GL-NFW55-D |
| 8 | Plastic Handle (Pemegang Plastik) | HL-FW | HL-FW | HL-FW | HL-FW | HL-FW |
| 9 | Oven Lamp without Bulb (Lampu Oven tanpa Mentol) | LE-FW-LAMP | LE-FW-LAMP | LE-FW-LAMP | LE-FW-LAMP | LE-FW-LAMP |
| 10 | Back Glass (For One Side Sliding Only) Kaca Belakang (Untuk Digelongsorkan Di Sebelah Sahaja) | GL-NFW35-B | GL-NFW40-B | GL-NFW45-B | GL-NFW50-B | GL-NFW55-B |
| 11 | Analog Thermometer (Termometer Analog) | TM-TM120 | TM-TM120 | TM-TM120 | TM-TM120 | TM-TM120 |